

## Power On Instruction for barebone/ system using AC power <u>Adapter</u>

Step 1: Connect the AC power adapter to the power connector on the back of chassis.



Step 2: Connect the power cable to the electric outlet.



Step 3: Connect the power cable to the AC power adapter.

